



Toshiba Satellite 1415-S105 RAM Replacement

Toshiba Satellite 1451-S105 RAM replacement or upgrade.

Written By: Kiril Lange



INTRODUCTION

Upgrading the RAM is a straightforward process that can significantly improve performance.


Two RAM slots allow up to 512MB of PC1600 DDR SDRAM.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Memory Cover



- The RAM access panel is located near the middle of the bottom.

Step 2





- Unscrew the single screw labeled F4 on the panel.

Step 3





- Using a spudger, inserted into the notch under the screw hole, pry open and remove the cover.

Step 4 — RAM



- Pull outward on each pair of restraining clips to free each chip.

Step 5 — Removal



- The RAM chips can now be pulled out.
- ⓘ This laptop supports a maximum of two memory modules. The largest capacity for each is 256MB of PC1600 DDR SDRAM.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 09:34:41 AM.